


Goldair™

PLATINUM



WiFi Instructions

Electronic Inverter Panel Heater with WiFi



Model: GPPH77o, GPPH78o

Wifi – Downloading and Setting up APP

This APP is supported only on 2.4GHz Wifi channels.

The Goldair app and device pairing process require your 2.4ghz connection to be separated from your 5ghz connection. For instructions on how to do this please contact your internet provider.




Please note, we endeavour to keep our app up to date as devices and software continue to adapt and evolve. However, with ever changing technology and software we cannot guarantee as models age that their Wifi operation will continue to be supported. If you feel like the day-to-day functionality of your app is impacted, please contact our customer services team.

Download Goldair mobile APP

- Open the APP Store or Google Play on your mobile phone.
- Open 'Search' and enter 'Goldair'
- Click 'GET' and begin to download and install.

Once downloaded to your phone open the APP

- Tap REGISTER near the bottom of the screen.
- Read and agree to the Privacy Policy.
- Add your email address.
- Tap 'Obtain verification code'





You will then receive an email with a verification code.

- Enter the verification code from your email.
- Create a password.
- Then tap confirm.

If you haven't received a verification code via email, tap the resend button and when the verification code is received follow above steps.


Your APP is now registered and ready for pairing to your device.




Pairing APP to Device

Connect with 2.4ghz Wifi Network


On the Home screen, tap 'Add Device' or the '+' icon.



Using the categories on the left, navigate to your device and tap on the image.



Confirm you are connected to a 2.4ghz network. If your 2.4ghz and 5ghz networks are dual banded, click 'Common router setting method' on how to split, or contact your internet provider.



Pairing APP to Device

Connect with 2.4ghz Wifi Network: EZ Mode


See instructions below to finalise your device pairing via EZ mode.

The app will default to EZ Mode in the right hand corner.

Ensure your device's Wifi LED is flashing rapidly.

If it is not, hold down the navigate to the 'Connection' function under Settings → Service to connect. for 5 seconds or until the Wifi icon begins to flash.

Click 'Confirm indicator rapidly blink' and 'Next'





Your device will now pair with the app.

Please ensure your device, modem and phone are as close together as possible and that your 2.4ghz Wifi signal is strong.

Once the device has paired, choose to rename it by tapping the Pen icon


Choose the most suitable room type and click 'Done' in the top right hand corner.



Pairing APP to Device

Connect with Bluetooth

As an alternative way of connecting your device, you can pair via Bluetooth. Please ensure you have Bluetooth switched on on your mobile phone.



On the Home screen, tap 'Add Device' or the '+' icon.

Ensure your device's Wifi LED is flashing rapidly.


If it is not, navigate to the 'Connection' function under Settings → Service to connect. for 5 seconds or until the Wifi icon begins to flash.



On the top right, click 'Auto Scan'

The app will now scan for Bluetooth devices.


When your device appears, click on the image.



Choose your 2.4ghz Wifi network and add in the password. Click 'Next'


Your device will now pair with the app.

Please ensure your device, modem and phone are as close together as possible.



Once the device has paired, choose to rename it by tapping the Pen icon

Choose the most suitable room type and click 'Done' in the top right hand corner.



Operating your Device from the APP

Device operation screen

The screenshot shows the 'My Heater' app interface with the following elements and annotations:

- Header:** A back arrow on the left and a pencil icon on the right labeled "Click to enter Device Settings".
- Temperature Controls:**
 - comfort · 27:** A slider with values 10 and 35. An arrow points to the slider with the text "Change Comfort mode target temperature setting (10-35°C)".
 - ECO · 4:** A slider with values 3 and 7. An arrow points to the slider with the text "Change Eco mode temperature to a deviation of 3-7°C from Comfort mode".
 - antifrost · 5:** A slider with values 3 and 7. An arrow points to the slider with the text "Change Antifrost temperature setting (3-7°C)".
- Heat Setting:** Three buttons labeled "comfort", "ECO", and "antifrost". An arrow points to the "comfort" button with the text "Choose heat setting: Comfort/Eco/Antifrost".
- Timer Display:** A section with three columns: "Temperature", "Countdown time", and "Current power". An arrow points to the "Countdown time" column with the text "Timer Display".
- Current Room Temperature:** The "Temperature" column shows "25 °C". An arrow points to this value with the text "Current room temperature".
- Power Setting:** The "Current power" column shows "0". An arrow points to this value with the text "Power setting".
- Bottom Controls:** Four circular buttons labeled "Power", "heating mode", "locked", and "Settings".
 - An arrow points to the "Power" button with the text "Power ON/OFF button".
 - An arrow points to the "heating mode" button with the text "Choose between AUTO and CUSTOM mode".
 - An arrow points to the "locked" button with the text "Turn child lock function ON/OFF".
 - An arrow points to the "Settings" button with the text "Click to enter the Settings screen for further options".

Operating your Device from the APP

Device operation screen




The screenshot shows the 'Settings' screen of an application. At the top, the status bar displays 'Spark NZ', signal strength, Wi-Fi, the time '2:13 PM', and battery level. The title 'Settings' is centered at the top of the screen. Below the title, there are several sections of settings, each with a list of options and a corresponding control (toggle switch or slider).

- Light:** A toggle switch is shown in the 'ON' position. An arrow points to it with the text: 'Choose Brightness mode: either 50% or 100% (default is at 100%)'.
- Sound:** A toggle switch is shown in the 'ON' position. An arrow points to it with the text: 'Turn Sound ON/OFF'.
- Open window:** A toggle switch is shown in the 'ON' position. An arrow points to it with the text: 'Turn Open Window function ON/OFF'.
- Automatically turn off LCD:** A toggle switch is shown in the 'ON' position. An arrow points to it with the text: 'Turn on Auto off LCD'.
- Timer:** A toggle switch is shown in the 'ON' position. An arrow points to it with the text: 'Turn Timer OFF function ON/OFF'.
- Timer time:** A chevron icon is shown. An arrow points to it with the text: 'Click to choose amount of time to lapse before timer turns heater OFF'.
- Program:** A toggle switch is shown in the 'OFF' position. An arrow points to it with the text: 'Turn Programm function ON'.
- Weekly plan:** A chevron icon is shown. An arrow points to it with the text: 'Press to enter the weekly plan and set up your program'.
- Custom power:** A slider is shown with the value '3' in red. The slider ranges from 0 to 5. An arrow points to the slider with the text: 'Choose power level for Custom mode (1-5)'.

Operating your Device from the APP

Weekly Program / Scheduler

WARNING: The scheduler should only to be used while you are in the house and it is recommended that you turn your heater off if leaving the premises.



Setting up your scheduler.

- Select your desired time on the Schedule edit screen and the hour block will turn grey. If you want to add additional hours, select them now and they will also turn grey.
- Tap 'temperature' and select desired temperature between 10-35
- Tap 'Copy' to add this time and temperature to additional days.
- This timer is now set and is colour coded per day. A new colour is used for each additional timer you create.

Operating your heater in scheduler mode.



- Turn on the program function in the app and your heater will enter schedule mode defaulting to 5 degrees and turning off your thermostat.
- When a scheduled time occurs, it will display your desired temperature and the heater will turn on.
- You will see the scheduler icon appear in the control panel.
- **Turning the heater off, or pressing buttons on the control panel will override the scheduler and revert you back to normal heating mode.**



WARNING: The scheduler should only to be used while you are in the house and it is recommended that you turn your heater off if leaving the premises.

Set up Tap-To-Run & Create Smart Scenes


Store your favourite settings or set up automated functions based on conditions in the 'Smart' part of your Goldair app.

Warning- you must remember to turn off any Smart functions prior to leaving the house or going away. We recommend you only operate your Goldair devices when someone is on the premises.

- Tap 'Smart' on the bottom of your mobile phone.
- Tap 'Create Scene' or the '+' icon on the top right.




Click 'Launch Tap-to-Run' to save your preferred settings on your devices to launch at the click of a button. Click 'Run the device' and choose a device. Preset your desired functions such as Power ON/OFF, temperature, mode and timer as per on the device's functions. Click 'Next'




Review your conditions and tasks on this screen, or choose to add another device or task by clicking the '+' icon.

Click Save to store your settings and your new task will appear on the Smart homepage. Click it to operate your desired task.



Set up Tap-To-Run & Create Smart Scenes



As well as setting up automated Tap-to-Run tasks, you can set conditions to operate your devices.

Weather:

Click 'When weather changes' to create a task based on your local outside weather. Choose between temperature, humidity, weather type, sunset/sunrise or wind speed. Select your desired condition and click 'Next'. Click 'Run the device' and choose a device. Preset your desired functions such as Power ON/OFF, temperature, mode and timer as per on the device's functions. Click 'Next'. Review your conditions and click save. Your automation will appear on the main Smart homepage.

Schedule:

Click 'Schedule' to create a task for your device at selected times of the day. Click 'Repeat' to choose days of the week or leave as 'Once' to operate as a one off. Choose your desired time from the scroll bar and click 'Next'. Click 'Run the device' and choose a device. Preset your desired functions such as Power ON/OFF, temperature, mode and timer as per on the device's functions. Click 'Next'. Review your conditions and click save. Your automation will appear on the main Smart homepage.

Status Change

Click 'When device status changes' to create a condition based on any function on your device, for example turning the Power Off when any device function is changed (to act as a child lock)

Voice Control

Once your smart scenes are set up, you can use Amazon Alexa or Google Home Routines to operate the scenes via voice control. Refer to your Amazon or Google Home user guides for instructions on how to pair your routine to smart scenes.

Operating your Device from the APP

Device settings:

The screenshot shows the settings for a device named "Heater" located in the "Living Room". The settings are organized into several sections:

- Header:** "Heater" (Room: Living Room) with an edit icon for name, location, and image.
- Device Information:** View your device information.
- Tap-to-Run and Automation:** View your tap-to-run and smart scene automations.
- Third-party Control:** Includes icons for Alexa and Google Assistant. Action: View compatible Voice Control devices & instructions on setting up.
- Device Offline Notification:** "Offline Notification" toggle switch. Action: Turn on notifications for when device goes Offline.
- Others:**
 - "Share Device": Share device with family (see instructions on next page).
 - "Create Group": Create group of devices (see instructions on next page).
 - "FAQ & Feedback": Read FAQs & submit feedback.
 - "Add to home screen": Add device shortcut to home screen.
 - "Check Device Network": Review device network. Includes a "Check Now" button.
 - "Device Update": View device updates & turn on automatic updates. Shows "No updates available".
 - "Remove Device": Remove device from app.

Operating your Device from the APP

Share device with family member:

- The person you add will need to have the Goldair APP installed on their phone.
- Enter your family member's details to share device operation with them.
- Tap 'Confirm' to complete the addition.

Remove family member from device:

- Tap 'Share Devices' to delete the number of the person you want to cancel. Tap 'Confirm' to confirm.

NOTE: There can only be one user operating the device at a time. The APP needs to be closed on all other devices to enable the sharing to work.

NOTE: If someone else sets up their phone on the same device without using the 'Device Sharing' the original phone will be disconnected and the device will disappear from the device list.

Add Member Completed

Name

Profile Photo 

Family members can control the device

Country/Region **New Zealand**

Account

Set as administrator

Once added, you can sign in to family with accounts registered with that phone number. The family administrator is granted all access, including removing the entire family. Regular members can only operate scenes and devices, they are not allowed to add and remove.

Group your devices:

Devices within the same group can be controlled simultaneously

- Under 'Create Group' setting, select all devices you wish to group together. Click 'Save'
- Enter a group name of choice. Click Save.

You can now operate all devices within this group simultaneously.

Select Device Save

Devices under same group can be controlled simultaneously

- My Heater
Home Master Bedroom
- My Heater
Home Living Room

Please enter the group name

My Heater Group

Cancel Save

Ungroup your devices:

- Click on to pen icon within device group
- Select 'Dismiss Group'

You have now deleted your group.

Group Details

Basic information of the group

- Modify group name My Heater Group
- Group position
- Manage Group Devices
- Sharing Group

Others

- Feedback


Dismiss group

How to connect to your Alexa devices


- Download the Goldair App and pair your device.

Note: change the name of the device to an easily identifiable name such as 'Bedroom Fan' or 'Living Room Heater'


Note: Ensure you have downloaded and have configured the Amazon Alexa app. Please see your Alexa device's user manual for instructions.



- On the main page of the Alexa app, click the 'More' icon in the bottom right hand side of the page. Click on 'Skills and Games'
- Click on the search icon in the top right hand corner




- Click on the search icon in the top right hand corner




How to connect to your Alexa devices


- Type 'Goldair' in the search bar and click to proceed.



- Click 'Enable to use' and type your phone number/ email address and password and click 'Link Now'



- Click 'Authorise' and go back to the Home screen. Your devices will now appear and you can operate using voice control.



How to connect to your Alexa devices

SUGGESTED VOICE COMMANDS

Note: Amazon and Google are in control of voice control functionality and terminology. Not all functions available via the controller or APP can be controlled via voice command.

Voice control on your device will allow you to turn ON and OFF and adjust the settings. Suggested voice commands to work with your Alexa device are:

Turning ON/OFF

Alexa, turn "Device Name" ON

Alexa, turn "Device Name" OFF

Adjust the settings

Alexa, turn "Device Name" to High (omit High with the desired setting or temperature)


How to connect to your Google Home devices

Follow the below instructions to connect your device to Google Home.


- Download the Goldair App and pair your device.

Note: change the name of the device to an easily identifiable name such as 'Bedroom Fan' or 'Living Room Heater'


Note: Ensure you have downloaded and have configured the Google Home/Assistant apps. Please see your Google device's user manual for instructions.



- On the main page of the Google Home app, click the '+' icon in the top left hand side of the page.




- Click 'Set up device'




How to connect to your Google Home devices


- Click 'Works with Google'



- Type 'Goldair' in the search bar and click to proceed.




- Type your phone number/ email address and password and click 'Link Now'




How to connect to your Google Home devices

- Click Authorise and all devices from your Goldair App will appear on screen.



- You have the option to add these to a particular room in your home
- When you go back to the Home screen, your devices will now appear and you can operate using voice control.



SUGGESTED VOICE COMMANDS

Note: Amazon and Google are in control of voice control functionality and terminology. Not all functions available via the controller or APP can be controlled via voice command.

Voice control on your device will allow you to turn ON and OFF and adjust the settings. Suggested voice commands to work with your Google device are:

Turning ON/OFF

Ok Google, turn "Device Name" ON
Ok Google, turn "Device Name" OFF

Adjust the settings

Ok Google, turn "Device Name" to High (omit High with the desired setting or temperature)

Goldair™

PLATINUM



CDB  Goldair™

New Zealand
PO Box 100707,
North Shore Mail Centre,
Auckland, 0745
www.goldair.co.nz

Australia
PO Box 574,
South Morang,
Victoria, 3752
www.goldair.com.au